

# Used Puffer® Recycling Program

## Puffer® Stacking Instructions

Proper stacking of Suterra Puffers® promotes safe transport and reduces potential damage. Puffer® hooks are not eligible for return and should be reused next season.



1. Stack the Puffers® with the door facing down.
2. Offset the first 2 Puffers® in the corner of bin as shown.
3. Align bin doors next to side of Puffer®.



4. Place a total of 9 Puffers® in the row.  
Note orientation of last 2 Puffers®
5. Follow this pattern for 2nd and 3rd rows.



6. Place Puffers® diagonally in bin as shown.
7. A total of 5 Puffers® can be placed diagonally.



8. Continue stacking Puffers® on top of each other.
9. Stack Puffers® 6 layers high, for a total of 192 Puffers®.

## Questions and Assistance

Email [customerreturns@suterra.com](mailto:customerreturns@suterra.com)



© 2023 Suterra LLC. All rights reserved. Suterra®, CheckMate® and the accompanying logos are trademarks of Suterra LLC. No part of this document may be reproduced, distributed, or transmitted in any form or by any means, including photocopying, recording, or other electronic or mechanical methods, without the prior written permission of Suterra LLC.

